



1. External Blinds & Awnings Fixing Screws and Bolts Guide

Below is a guide to the types of screws and fixings suitable for the secure fit of heavier Outdoor Blinds and Awnings.

Each situation is different and you will need to make your selection based on the type of Blind, the overall size, the surface you are installing to and it's exposure to weather. Its always best to oversecure. it's better to be safe than sorry!

Auto awning: up to 5000 wide, main head box brackets 60mm x 10g, 4 off with washer for timber install - 75mm x 8mm Dyna bolt for brick or concrete. Use 50mm x 10g, 8 off for securing the metal side runners and U brackets , include green raw plugs if installing into brick or concrete.

Ext Wire Guide Roller: up to 5000 wide, main head box brackets 60mm x 10g, 6 off with washer for timber install - 75mm x 8mm Dyna bolt for brick or concrete. For bottom of wire guide 40mm x 10g, 2 off - Use a green raw plug for brick or concrete. Alternatively use a 40mm x 6mm Dyna bolt.



Countersunk (Zenith)

10g x 50mm
Available in Metal or Timber thread
Stainless

Used to side fix channels or wire guide bottom bracket.



Wafer / Button Head (Buildex)

8g x 50mm
Available in Metal or Timber thread

Used to face fix channels.



Roofing & Cadding Hex Head (Buildex)

12g x 50mm
Available in Metal or Timber thread

Used to fix universal brackets.



Ramplug / Green Plug (Ramset)

50mm Length

Used to fit brick or concrete.



Dyna Bolt (Ramset)

6mm x 30mm

Used to face fix channels.



Dyna Bolt (Ramset)

8mm x 50mm

Used to fix universal brackets.

Countersunk (Ramset)

4.5mm x 30mm
Stainless

Used to side fix wire guide bottom brackets.