




## Zebra Blinds



### Parts Included.



**A**

Bracket  
Qty: 2, 3, 4\*



**B**

Child Safety Device  
Qty: 1



**C**

Installation Screws  
Qty: 4, 6, 8\*



**D**

Child Safety Screw  
Qty: 1

\* The quantity of brackets and screws supplied will vary depending on the width of the blind.



Check your installation surface in order to identify the most appropriate screws to use. See appendix at the end for a guide to fixing screws to different types of wall constructions.

Please note, we do not provide screws for specific surfaces as we are unable to determine the installation surface.

### Important Notes.

- Please check that all parts have been supplied before you begin to assemble your new Zebra Blind
- Do not operate the blind until it is fully installed
- The finished blind width is from the end of the left hand side of the head rail to the end of the right hand side of the head rail
- Ensure that the blind is mounted level for correct operation

### Video Instructions.



Scan the QR Code to view our online step by step video instructions.




## Zebra Blinds

### 1. Installing Mounting Brackets.


As per your order, determine the correct fitting location of mounting brackets and mark where you are going to install the brackets.

#### Inside Recess Mount



For **Inside Recess Mount** drill two screws per bracket through each bracket and into the top of the window frame. Place end brackets approximately 100mm in from the end, and evenly space the remaining brackets. We recommend installing your brackets towards the front of your Recess to avoid damage if you have window or door handles.

#### Outside Face Mount



For **Outside Face Mount** drill two screws per bracket through each bracket and into the outside of your architrave or wall. Place end brackets approximately 100mm in from the end, and evenly space the remaining brackets.



#### Hot Tip.

Marking holes with your pencil and pre drilling 2mm holes can make drilling in your screws much easier. Just ensure that the pilot whole is smaller than the thickness of the screw



**Zebra Blinds**

**2. Attach Blind to Brackets.**

Align the back of the headrail with the bottom hooks on the bracket (Figure 1).

Lift the front of the headrail so that the clips on the front of the head rail lock into place (Figure 2).

To release, press the clear plastic release button on the front of each bracket and lower the front of the headrail.




Figure 1




Figure 2

**3. Operate the Blind.**

Using the cord/chain, draw the blind up and down several times to ensure the blind operates correctly.

**4. Attach Child Safety Device.**

Secure the child safety device to the wall beside the blind, ensuring the cord/chain is not too tight, as this may restrict smooth operation. See fitting instructions on the following page.

**Warning:**

- The chain/cord tension device must be fitted to ensure child safety
- The chain tension device is to be positioned at the bottom of the chain/cord loop
- It can be fitted to the inside of the reveal (frame) or in front of the reveal (frame)





## Zebra Blinds

### Child Safety Fitting Instructions.

Position the tension device at the bottom of the chain/cord loop (Figure 1).

Install the tension device onto the reveal/frame using child safety screw (part D), making sure that the loop chain/cord hangs with minimal tension (Figure 2).

Figure 1





Figure 2



## 5. Cleaning and Maintaining Zebra Blinds.

### Quick Clean

Check what material your blinds are made of. If they are waterproof, you can use a damp cloth to wipe them down. If not, you can use the brush attachment on your vacuum cleaner.

Extend your Zebra Blinds all the way down and wipe or gently vacuum the surface of both sides of the blind. If your blind is damp, ensure that you allow your blinds to completely dry before retracting them or you risk your blinds developing mould and mildew.

### Deep Clean


We recommend contacting a professional cleaning company to deep clean your blinds. Otherwise, get in contact with the team at Blinds on the Net for a new set of blinds to freshen up the look of your home.



# Appendix.


## 1. Interior Fixing Screws Guide

### Timber Recesses or Architraves



It is sometimes a good idea to mark where you want your brackets to go and pre drill a small hole where you have marked. You **MUST** ensure that the hole you drill is smaller than the diameter of the timber screw you are going to use so the screw can still screw in tight. The reason to pre drill your hole is to stop the timber splitting.

### Aluminium Window Frames




For installing into Aluminium frames we once again suggest marking the holes first, however pre-drilling is not necessary this time so long as you buy "self drilling" screws. These can be picked up from your local hardware and will drill into the aluminium frame as it screws into place. So line up the brackets to the marked holes and simply drill the brackets into place.

### Gyprock Installations



For those of you who are installing into Gyprock, we strongly recommend using "Wall Mates" (these can be found at your local hardware) or similar, these are larger outer screws that drill into the Gyprock and give a stronger base for drilling in screws after. Firstly place your brackets where you want to install them and then mark the holes in the brackets. Screw in your "Wall Mates" into the gyprock. Once this is done, you can line your brackets up with the "Wall Mates" and then use a normal timber screw (pictured above) to secure the brackets to the wall mates in the gyprock.

### Brick or Masonry installations



your brackets in position and mark where the holes are in the brackets. Then, Pre-drill your walls to accept the red masonry wall plugs. You will require a 5.5mm-6mm masonry drill bit ( a normal 5.5-6mm drill bit won't work, it need to be a specific masonry drill bit), we suggest asking at your local hardware but 6mm should be fine however you do want a nice tight fit for the red wall plugs. Once you have predrilled your holes, tap the red masonry wall plugs into place with a hammer.

Once you have the red masonry wall plugs in place, you are ready to install the brackets, simply screw into the centre of the wall plugs for a secure fixing.